

FIG.3




FIG.4/1




FIG.4/2




FIG.5






FIG. 6









FIG.9

FIG.10

Message Router
25000







FIG.11








FIG.13

FIG.14





Sync System

17100

FIG.15

On purge timer

17102

Sync system init

17101






FIG.16

FIG. 17

Command Scenarios





Self Configuring
Command and Control
15100

FIG.18




FIG.19




FIG.20




FIG.22




FIG.21




FIG.23




FIG.24





FIG.25



Keyword Scenarios
14000

FIG.26






FIG.27

FIG.28

Graphical UI 18100





Text UI 18200

FIG.29






FIG.30

GUI Unit Update 18400
FIG.31





GUI Env Update
18500

FIG.32